



Installation tips for LOXX® upper parts and lower parts with washer:



Right installation:

Make sure that the washer is at least flush with the thread of the upper or lower part.



Wrong installation:

The system won't close correctly if the washer is not flush with the thread of the upper or lower part.

